

SPEED MOTO BRAKE COOLING

Installation instructions



SPEEDMOTO

The installation

1.
Remove both OEM Screws from the Brake caliper.
2. *Remove the lower screw from the fork protector*



3. *Use the OEM screws to mount the brake cooling*
4. *Use 45 NM for the brake caliper screws*
Use 5NM for the fork cover screw



Speed Engineering GmbH
Kupferstraße 7
44577 Castrop-Rauxel
info@speedengineering.de
WWW.SPEEDENGINEERING.DE