

The installation

1.

Remove both OEM Screws from the Brake caliper.

2. *Remove the lower screw from the fork protector*



3. *Use the OEM screws to mount the brake cooling*

4. *Use 45 NM for the brake caliper screws*

Use 5NM for the fork cover screw