

SPEED MOTO BRAKE COOLING

Installation instructions



SPEEDMOTO

The installation

1. Remove both OEM Screws from the Brake caliper.
2. Remove the lower screw from the fork protector



3. Use the OEM screws to mount the brake cooling

4. Use 45 NM for the brake caliper screws
Use 5NM for the fork cover screw



**Speed Engineering GmbH
Kupferstraße 7
44577 Castrop-Rauxel
info@speedengineering.de
WWW.SPEEDENGINEERING.DE**